



BT36, BT42, BT48 Assembly Instructions

1. Lay all out all parts as shown in the picture below. Please remember to lift your table top **BY THE FRAME**, not by the planks.
2. Insure that you have the following items: 1 pkg screws and the included bit
 - : 2 leg sub-assemblies
 - : 2 wrap pieces labeled "A" and "B"
 - : 1 table top assembly




3. Insert 4 screws into the brace on each side of the table top as shown below. On each brace, run one of the screws through the brace piece until it slightly protrudes as shown at left. This will help you align the leg assembly properly.



4. The braces are labeled numbers 1-4, these numbers correspond to the leg assemblies. Match the leg assembly numbers up with the appropriate brace. The protruding screw will align with the pre-drilled hole on

the leg as seen in picture at right. Carefully tighten the screw until it is seated, but **DO NOT OVERTIGHTEN**.

5. Continue tightening screws until all 4 screws are seated, then repeat step 4 for the other leg assembly.



- You are now ready to attach the wrap pieces labeled "A" and "B". Starting with wrap "A", insert all 4 screws, and run the top screws through the wrap until it slightly protrudes, as seen at below left. The arrow should be pointing "up", and will match the arrow on the corresponding leg.



- Align the protruding screws with the pre drilled holes as seen at above right and tighten until seated, be careful not to overtighten! You can then tighten the remaining two screws in the wrap piece.
- Repeat the same procedure with the piece labeled 'wrap B', once complete your table will be ready to use!! ENJOY!!

